

IMPORTANT SAFETY INFORMATION. READ AND FOLLOW ALL SAFETY INSTRUCTIONS. Follow label information and instructions concerning Wet or Damp Locations, installation near combustible materials, insulation, building materials, and proper lamping. Do not install in areas subject to combustible vapors or gases. Before wiring to power supply and during servicing or relamping, turn off power at fuse or circuit breaker. All servicing or relamping must be performed by qualified service personnel. Product must be grounded to avoid potential electric shock or other potential hazard. Product must be mounted in locations and at heights and in a manner consistent with its intended use, and in compliance with the National Electrical Code and local codes. The use of accessory equipment not recommended by the manufacturer or installed contrary to instructions may cause an unsafe condition. Do not block light emanating from product in whole or part, as this may cause an unsafe condition. Do not allow items such as drapes, curtains, screens or the like to come into contact with the product or to block light from the product, as this may cause an unsafe condition.

# INSTALLATION INSTRUCTIONS

## TA60, TA65, TAW65, TA66, TAW66

\*\*\*\*\*  
WARNING: If any special control devices are used with this fixture, follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.  
\*\*\*\*\*

- 1- To adjust Fixture to correct Ceiling thickness, loosen the Wingnut (1) inside the Housing (2) and lower the Housing (2) until the bottom edge is flush with the Ceiling (3). Then re-tighten the Wingnut (1).
- 2- Remove Eyeball (4) from Trim (7). Slide Socket (6) down along length of Mounting Spring (8) and remove. Slip Socket (6) down through center of Trim (7).
- 3- Attach end of Mounting Spring (8) to rectangular slots of Socket hole in Mounting Bracket (5). Push Trim (7) upward until flush with Ceiling (3).
- 4- Attach Socket (6) to Eyeball (4). Compress Socket Spring Legs (10) while inserting into Slots (9) of opening in top of Eyeball (4). Then release.
- 5- Snap Eyeball (4) back into Trim (5).
- 6- Install Lamp (NOT FURNISHED).

**CAUTION: ALL GLASS IS FRAGILE, USE CARE WHEN HANDLING LAMP.**

